




Thank you for choosing Acesori. Please follow both sides of this user guide to ensure proper use.

**1.** There are several metal rings included in the kit. Remove the thin film on a ring to expose the adhesive and place it carefully around the camera lens of your phone. Allow a few minutes for the adhesive to dry fully. Do not place the ring around a phone case.



**2.** Once the ring is securely on the phone, you can use one of the lenses in the kit. There are 3 lenses; fish eye, wide angle and macro lens. Take note that the macro lens is attached to the wide angle lens. To use the macro lens, simply unscrew it from the wide angle lens. When you need to use the wide angle lens again, screw it onto the macro lens.




**3.** Line-up the magnetic lens to the ring on the phone. The lens will snap in place on the phone. Be sure the lens is centered directly around the smartphone camera lens. When you are done using the lens, carefully pull it off the phone. You may leave the metal ring on.




**4.** Included in the kit are lens covers. When you are not using any of the lenses, we recommend placing the appropriate cover over the lens. Also included is a carrying pouch made to fit the lenses for extra protection.



**5.** To easily transport your lenses, lanyards are included. In the same way you attach a lens to the metal ring on your phone, you can also attach a lens to the metal plate on the lanyard. Finally, you may use the included micro fiber cloth to keep the lenses clean.



**NOTE:**  
How to use  
the Macro and  
Wide Angle  
lenses



## Warranty Information

Acesori is pleased to cover your Acesori accessory for a period of one (1) year from the date of purchase. Please contact us any time within that year for any technical assistance with your Acesori item.

Email: [support@acesori.com](mailto:support@acesori.com)

Website: [www.acesori.com](http://www.acesori.com)

**See website for full warranty conditions**