



## **User Guide**

Thank you for choosing Acesori. Please follow both sides of this guide to ensure proper use.

### **Turning on the Acesori PocketCast?**

To turn on your Acesori PocketCast hold the Play/Call button (center) until the led on the left side of the device blinks rapid purple then blue.

### **Is my Acesori PocketCast on?**

You'll know your Acesori PocketCast is on by the LED indicator on the left side. When the PocketCast **is not** paired with any device the blue LED light will blink once every 5 seconds. When the PocketCast **is** paired with a device the blue LED light will blink twice every 5 seconds.

### **How to pair your Acesori PocketCast?**

Go to settings in your personal device and find "EB-601" under your Bluetooth devices. Acesori PocketCast should automatically pair. Use the included AUX cord to plug your Acesori PocketCast into headphones, car stereo, home receiver or any device with an AUX 3.5mm input and you're now Bluetooth ready!

### **How to charge your Acesori PocketCast?**

Plug the MicroUSB (small) connector into the Acesori PocketCast and plug the USB (large) connector into a USB power source such as a USB wall charger, laptop or other device. A red LED light will show when charging and the light will go off when fully charged.

## **Turning off your Acesori PocketCast?**

Similar to turning on your Acesori PocketCast, hold the play/call (center) button until the led on the side of the device blinks purple 3 times

## **Controlling your music/audio**

**Volume:** Touch the "+ / -" buttons to raise or lower the volume of the receiver

**Track:** Touch the "|<< / >>|" buttons to go to the previous and next audio track.

**Play/Pause:** Touch the ">||" button

## **Phone and calling functions**

**Answer Call:** Touch the ">||" button to answer or hangout a phone call

**Redial:** Quickly double tap the ">||" button

**MIC:** The built-in mic is next to the AUX output

---

## **Warranty**

Acesori is pleased to cover your Acesori accessory for a period of one (1) year from date of purchase. Please contact us any time within that year for any technical assistance with your Acesori item.

Questions? Comments? Concerns? Support?

Email: [support@acesori.com](mailto:support@acesori.com)

Website: [www.acesori.com](http://www.acesori.com)

**See website for full warranty conditions**