


Head Guard

HOW TO MEASURE YOURSELF

HEAD SIZE: MEASURE AROUND YOUR SKULL, JUST ABOVE THE EARS. PLEASE NOTE THAT THERE IS JUST ONE SIZE OF THE HEAD GUARD AND THE CIRCUMFERENCE IS ADJUSTABLE.

HEAD CIRCUMFERENCE



SIZE	HEAD MEASUREMENT
SMALL	58-62
MEDIUM	63-66
LARGE	67-71
X- LARGE	71-75