



# BUCKET CART INSTRUCTIONS

Featuring a design that easily assembles and disassembles for convenient transportation and space saving, these bucket carts are the easiest way to haul buckets at shows or at home.

## Setup Instructions:

1. On each side of the Base Piece (A) of your cart, slide the Extended Hub (B) of each wheel onto the Axle (C) (Figure 1), ensuring the flush hub is on the outside of the cart. Secure both wheels with cotter pins (Figure 2).
2. Once the wheels are secured, place the Base Piece (A) on even ground. Slide the bottom two bars of the Middle Piece (D) onto the two top bars of the Base Piece (A) (Figure 3).
3. Slide the bottom two bars of the Top Piece (E) onto the top two bars of the Middle Piece (D) (Figure 4).
4. Secure all four connection points (Figure 4) with hinge pins (Figure 5), ensuring pins are securely fastened.

