




STALL FEEDER ASSEMBLY INSTRUCTIONS

This durable 2-head stall feeder is the ultimate solution for feeding multiple animals at once and ensuring proper feed consumption. The streamlined design folds completely flat for convenient storage and transportation, and add-ons are unlimited—purchase additional stall pieces to create a 3-head, 4-head or even 15-head stall feeder!

This product is not intended for confinement. Never leave animals unattended while using this product.

Pieces Included:

- A. (3) Stall Divider Panels
- B. (2) Rear Door Panels
- C. (2) Front Panels
- D. (4) Crossbars
- E. (6) Corner Pins



Set-Up Instructions:

Please note: Each stall divider panel has holes drilled along the top edge. Make sure the holes are all facing up during assembly.

1. First you'll need one divider panel, one front panel and one corner pin. Place the panels square to one another so that they form a right angle and the hinges line up along the edges. **Figure 1**
2. Slide the pin through the hinges to secure the panels together. **Figure 2**



FIGURE 1



FIGURE 2




- Grab a second divider panel and place it on the other side of the front panel, so that it's parallel to the first divider panel. Take the second front panel and place it right beside the first. **Figure 3**
- The front panels and the second divider panel should form a T-shape, with all three sets of hinges lining up in the center. Slide a corner pin through the hinges to secure the three pieces together. **Figure 4**



FIGURE 3



FIGURE 4



- Place the third divider panel on the other side of the front panel. Secure with a pin. **Figure 5**
- Add a rear door panel to the back of the stall feeder on either side. Secure the outside corner with a pin. **Figure 6 & 7**



FIGURE 5



FIGURE 6



FIGURE 7

- Repeat step 6 on the other side. **Figures 8 & 9**



FIGURE 8



FIGURE 9

8. The rear door panels should form a T-shape with the center divider panel. Secure all three pieces together with a pin. **Figure 10 & 11**
9. Place your crossbars in the holes along the top edges of the divider panels. They should be arranged diagonally across the top of each stall (two crossbars on each side). Make sure the front and back crossbars are going in opposite directions. **Figure 12 & 13**
10. Place your feed pan holders on the inside of the front panels at your desired height. Your 2-head stall feeder is now complete! **Figure 14**



FIGURE 10



FIGURE 11



FIGURE 12

Notes:

- The rear doors feature spring-loaded latches for security. Simply lift the latch to open the door. The latch will secure automatically when the door is pushed shut. **Figure 15**
- To add on to your 2-head stall feeder, simply repeat steps 3 – 10 with your additional pieces. Each stall feeder addition (69646-01) includes (1) divider panel, (1) rear door panel, (1) front panel, (2) pins and (2) crossbars. You can add on as many feeders as needed.




FIGURE 13




FIGURE 15




FIGURE 14