



No More Pain
Ergonomics



Congratulations on your new

Mini Compact Ergonomic Keyboard!

CONTACT US

www.nomorepainergonomics.com.au

info@nomorepainergonomics.com.au

Quick Start 

Product Content:

1 x Mini Compact Ergonomic Keyboard

System Requirements:

- Mac OS X (10.28+)

Specifications:

- Connection via: Bluetooth V3.0
- Dimensions 285.5x120.5x18mm
- Operating Range Up to 10 meters
- Pairing Name Bluetooth Keyboard
- Power Supply 2x AAA batteries (Not included)
- Key Life 5 Million clicks

Getting Started

1. System requirements

- iPad, iPhone – All versions
- Bluetooth-enabled PCs or Laptops with Windows XP ~10
- Bluetooth-enabled iMac / Macbooks with Mac OS X 10.2.8 or above (note that some exceptions may apply. This keyboard may not be compatible with the Mac mini.
- Smartphones or tablets with Android 3.0 and above (with Bluetooth HID profile)
- Windows Mobile 5.0 and above



2. Pairing keyboard methods

Pairing with an iPad/ iPhone

- Step 1: Press and hold 'FN + C' for a moment and the LED light icon will flash red.
- Step 2: On the iPad/iPhone, select: Setting- General- Bluetooth- On.
- Step 3: The iPad/iPhone will display "Bluetooth keyboard" as an available device.
- Step 4: Select "Bluetooth keyboard", the keyboard will now be paired to the iPad/iPhone.

Pairing with Tablets , Smartphones, Laptop and Desktop computers, etc.

- Step 1: Press and hold FN + C for a moment and the LED light icon will flash red (3 min. long) until a BT connection is established. it disappears when connected
- Step 2: Go to your "settings" screen on your tablet, laptop, smartphone or other Bluetooth –enabled devices and go to the Bluetooth setting menu and activate its Bluetooth function and search for the keyboard.
- Step 3: Once the Bluetooth keyboard has been found, select its name to connect.

Note:

- Only one device can be actively paired at one time.
- After pairing for the first time, your device will connect to the keyboard automatically when switching on the keyboard.
- In case of connection failure, delete the pairing record from your device, and try the above pairing procedures again.

Function Keys

Function key features may have variations depending on the operation system version and devices

- ESC - Home
- F1 - Brightness down/Return
- F2 - Brightness Up/Email
- F3 - Virtual Keyboard/Menu/Right Click
- F4 - Screen Capture/Media Player
- F5 - Search
- F6 - Language Exchange
- F7 - Previous Track
- F8 - Play/Pause
- F9 - Next Track
- F10 - Mute
- F11 - Volume Down
- F12 - Volume Up
- Del - Screen Lock



Important Guidelines:

- Read the user manual carefully and keep it for reference.
- Use this product only as described in this user manual.
- Do not place heavy objects on the keyboard cover.
- Keep the product away from water, oil, chemicals, and organic liquids.
- Clean the product by lightly rubbing it with a slightly damp cloth.



Guidelines For Protection of The Environment

Your product is designed and manufactured with high quality materials and components which can be recycled and reused. This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This crossed-out wheelie bin symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Battery/batteries disposal Check the local regulations concerning the disposal and processing of batteries or contact the town hall or your waste disposal company or with the store where you purchased the product. The battery/batteries should never be disposed of in the normal garbage waste. Use a battery processing authority in your area or community, when and where available.

- Disclaimer
- Apple™ is a trademark of Apple Corporation.
- Android™ is a trademark of Google Inc.
- Windows™ is a trademark of Microsoft Corporation.



Troubleshooting

The keyboard has stopped responding:

- Replace with new batteries
- Follow the above steps to disconnect and reconnect with devices via Bluetooth
- The keyboard will enter into the sleep mode after being idle for 15 minutes. To activate the keyboard, press any key and wait 3 seconds.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

If the above does not fix the issue, please contact us on the below:
info@nomorepainergonomics.com.au

FOR INFORMATION ABOUT:

Warranty Policy
Good Ergonomics
Other Products

Check our website: www.nomorepainergonomics.com.au



No More Pain
Ergonomics