

Ozone Filter Instructions

Ozone Emission Removal Filter Reusable for up to 20 years. NOT washable. Eliminates ozone emissions.



Scan to lear More!

Before First Use

- 1. Remove this plastic covering from the Ozone Emission Removal Filter.
- 2. Slide the unwrapped Ozone Emission Removal Filter back into Slot 3.
- 3. Repeat this process with the other filters.

Cleaning the Ozone Emission Removal Filter

The Ozone Emission Removal Filter does not need to be cleaned in order to remain effective. However, if you wish to clean it, follow the instructions below and remember that when working with any used filter, wear a face mask and gloves and work outside or in a well-ventilated area.

- 1. Carefully remove the Ozone Emission Removal Filter from its slot.
- Gently clean the Ozone Emission Removal Filter using the brush attachment on your vacuum cleaner. Alternately, you can use a soft, non-abrasive brush and a garbage bag, brushing the surface straight down into the garbage bag.
- 3. Repeat this process on the other side.
- 4. When finished, reinstall the Ozone Emission Removal Filter.



Para la versión en español de este manual, visita www.nuwavenow.com

Cleaning instructions can also be found in your Owners' Manual or visit us at www.nuwavenow.com/faq/oxypure

Questions: Call Customer Service at 877-689-2838 Mon.-Fri. from 7:30am-4:30pm or email help@nuwavenow.com