

QUICK START GUIDE

KEYCHAIN POWER BANK



WHAT'S INCLUDED

- (1) Keychain Power Bank
- (1) Carabiner Ring
- (1) 40" 3-in-1 USB Charging Cable

COMPONENTS

1. Carabiner Ring
2. Power Indicator Light
3. USB Charging Port (Output)
4. Type-C Port (Input)
5. USB Plug
6. Lightning Charger
7. Micro Charger
8. Type-C Charger

TECH SPECS

Model: BND-KPPBL-XXX

Battery Capacity: 2,500mAh

Recharge Time (from 0%): 3 hours

Type-C Charging Port (Input): 5V/2A

USB Charging Port (Output): 5V/2A

Dimensions: 1.2 in x 0.86 in x 4.4 in

Weight: 0.148 lb

COMPATIBILITY

Micro: Select Tracfones, Speakers, Cameras, Power Banks, & More

Lightning: Compatible with iPhones, AirPods, & Most Apple Devices

Type-C: Compatible with newer devices by Samsung, Microsoft, LG, Google, Huawei, select Apple iPads (2018 and newer), select Tracfones, and More.



Designed in the USA. Made in China. Boundless™ and Boundless Innovations™ are trademarks of Boundless Innovations, Inc. All rights reserved. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

BoundlessInnovations.com
Support@BoundlessInnovations.com
(888) 310-0007

Boundless Innovations
1412 Ridgeview Drive
McHenry, IL 60050

© Boundless Innovations, Inc.



Scan to learn more about using the features of your Keychain Power Bank



@BoundlessInnov

GETTING STARTED

The Keychain Power Bank will arrive with a partial charge. It is recommended to charge the battery to 100% upon arrival and after each use. The included Charging Cable is reversible and can recharge the power bank or another USB-chargeable device.

CHARGING THE POWER BANK

Plug the Type-C Connector into the Type-C Input and a USB charger (not included). The Power Indicator Light will blink red while charging and will go solid once it is fully charged.

Carabiner Ring

The Carabiner Ring will come detached from the Keychain Power Bank. Push the lever to attach it to the Power Bank, as well to a purse or keychain.



The Power Indicator Light will blink blue once the battery level reaches 5% to indicate it is time to recharge.



RECHARGING DEVICES

Plug a USB charging cable into the USB Output then into a USB chargeable device. The device will begin to charge.

Using the Included 3-in-1 Charging Cable

Plug the USB end of the cable into the Keychain Power Bank's USB port. Choose the appropriate charger from the other end of the cable and connect to the device. The device will begin to charge.

