USER MANUAL

ULTRA-SLIM POWER BANK






- (1) Ultra-Slim Power Bank
- \cdot (3) Short Cables
 - \cdot Type-C to Type-C
 - \cdot Type-C to Micro
 - \cdot Type-C to Lightning
- \cdot (1) 24" Type-C to USB Charging Cable
- \cdot (1) Microfiber Pouch

COMPONENTS





PRODUCT SETUP -

GETTING STARTED

The Ultra-Slim Power Bank will arrive with a partial charge. It is recommended to charge the battery to 100% upon arrival and after each use.

POWER ON/OFF

The Ultra-Slim Power Bank powers on and off automatically while charging.

RECHARGING THE UNIT

To recharge, use the included Type-C to USB Charging Cable and any USB power source (i.e. a wall adapter, computer USB port, car charger, etc. – not included). Once plugged into a power source, the Battery Level Dispay will illuminte with the current percentage of battery. As the power bank charges, the level will blink and count up. The power bank is fully charged when the level has reached 100%. Select your compatible charging method from below and connect the Ultimate Power Bank to a device. The device will automatically begin to charge.

- Type-C to Type-C
- Type-C to Micro
- Type-C to Lightning

COMPATIBILITY

MICRO CABLE

CHARGING

Compatible with select Samsung, Amazon Kindle, and Motorola devices as well as cameras, power banks, speakers, controllers, and more.

BUILT-IN TYPE-C CABLE

Compatible with most new Samsung, Google, Motorola, Microsoft, LG, and Apple iPads 2018 and newer.

BUILT-IN LIGHTNING CABLE

Compatible with most Apple Devices.



Designed in the USA. Made in China. All rights reserved. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

BoundlessInnovations.com

Support@BoundlessInnovations.com (888) 310-0007

> Boundless Innovations 1412 Ridgeview Drive McHenry, IL 60050

© Boundless Innovations, Inc.





Scan to learn more about using the features of your Ultra-Slim Power Bank



TECH SPECS

Model: BND-SPB1--XXX

Dimensions: 0.256 in x 2.36 in x 3.54 in

Weight: X.XX oz

Type-C Input: 18W | 5V 3A | 9V 2A

Type-C Output: 20W Battery Capacity: 5,000mah Battery Level Indicator: Digital LCD Display

Recharge Time: +/- X hours

SAFETY INFO

By using the Boundless™ 5000mAh Ultra-Slim Power Bank Mega Power Station w/Type-C Port & Charging Cables ("Ultra-Slim Power Bank"), you hereby agree that Boundless Innovations, Inc. an Illinois corporation (and its affiliates, related companies, officers, and employees) shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Ultra-Slim Power Bank. By using the Ultra-Slim Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions, and general safety information in this user manual. By using the Ultra-Slim Power Bank, you further agree to hold harmless Boundless Innovations, Inc. (and its affiliates, related companies, officers, directors, shareholders, and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury, or loss of life) relating in any manner whatsoever to your use of the Ultra-Slim Power Bank

• The Ultra-Slim Power Bank is **NOT** a toy and should be kept away from children.

WARNING

- Do NOT use the Ultra-Slim Power Bank near a magnetic or electric field.
- Do NOT use the Ultra-Slim Power Bank in direct sunlight or extreme heat for extended periods of time.
- Do NOT use the Ultra-Slim Power Bank if it has been damaged and/or modified.
- Do NOT subject the Ultra-Slim Power Bank to harsh chemicals.
- Do **NOT** submerge the Ultra-Slim Power Bank or its accessories in water.
- Do NOT store the Ultra-Slim Power Bank where temperatures will exceed 140° F (60° C).
- Do NOT insert any foreign objects into the openings or port of the Ultra-Slim Power Bank.
- Do **NOT** charge the Ultra-Slim Power Bank in high humidity conditions.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do NOT attempt to disassemble, repair, or open the Ultra-Slim Power Bank or its accessories in any way.

- Do NOT paint or apply coatings to the Ultra-Slim Power Bank as you might affect moving parts or damage internal components.
- Do **NOT** leave the Ultra-Slim Power Bank plugged in for extended periods of time. Doing so may decrease the life of the battery life.
- Batteries should be recycled or disposed of, as per state and local guidelines.

AIR TRAVEL

 You may carry the Ultra-Slim Power Bank on an airplane. Do **NOT** travel with the Ultra-Slim Power Bank in your checked baggage.

For more information, visit: https://www.faa.gov/travelers