



ATMOSPHERE GLOBES A4, B4, P4

Caring for your globe

Firstly, unplug your globe and allow it to cool down. Clean the surfaces by using a damp cloth. Use water only, never use alcohol or other cleaning solvents which would permanently damage the surfaces.

Instructions for assembling the globe

Screw in the lower part of the arc to the base (See picture A) by turning the base (see picture B).

Instructions for changing the bulb

Caution!

Always use the correct bulb size: do not exceed 25 Watt, type E 14, 2200 - 2400 Volt.

- Disconnect the globe from the electricity supply and wait a few minutes for the bulb to cool down
- Remove the plastic top pin following the instructions 1 to 4.
- Take the globe apart following the instructions 5 and 6.
- Once the globe is free replace the bulb (type E14) by screwing it in.
- Put the globe together following the illustrations from 6 to 1.