

TRIGGR ULTRABUDS N5

USER MANUAL

INTRODUCTION

Welcome to the TRIGGR Tribe

Introducing Ultrabuds N5, the pinnacle of audio innovation that is meticulously designed to deliver an unparalleled sound journey, setting new standards in the world of premium audio. Ultrabuds N5 automatically adjusts audio frequencies to optimize vocal richness, making every word pronounced with remarkable precision, transforming your phone calls into conversations that rival face-to-face interactions in terms of clarity and quality. Experience a world free of distractions with our advanced noise-cancellation technology, allowing you to immerse yourself fully in your audio while effortlessly tuning out the outside world. With a battery life that keeps you connected throughout the day and dynamic touch controls for seamless playback and calls, Ultrabuds cater to your every need.

But that's not all - these earbuds feature low-latency technology that's perfect for gaming enthusiasts. In high-intensity gaming scenarios where split-second reactions are essential, our signature sound quality ensures you're always one step ahead. Get ready to game like never before and take your audio adventures to the next level with Ultrabuds N5.

PRODUCT LAYOUT



- 1. Charging Case
- 2. Eartips
- 3. Charging Port
- 4. Indicator Light
- 5. Earbuds

HOW TO PAIR

Step 1

Ensure sufficient charging of your device before using the earbuds.

Step 2


Removing the earbuds from the case will turn them ON and they will enter pairing mode.

Step 3

Go to the Bluetooth settings of your phone and check for new devices. Select "TRIGGR Ultrabuds N5". You will hear the notification prompt on a successful connection.

Note - If you do not connect to any device for 300 seconds (5 mins) of entering pairing mode, then both earbuds will automatically turn OFF.

Close and open the lid to turn it ON again



TOUCH CONTROLS

Play/Pause

Single Tap the touch sensor on any one earbud to pause music.

Single Tap the touch sensor on any one earbud to resume playing music.

Changing Songs

Double Tap the touch sensor on the right earbud to go to the next song.

Double Tap the touch sensor on the left earbud to go to the previous music.

Adjusting Volume

Triple Tap the touch sensor on the right earbud to increase volume.

Triple Tap the touch sensor on the left earbud to decrease the volume.

Voice Assistance

Quadruple tap the touch sensor on any earbud to activate the voice assistance.

Game/Music Mode

Long Press the touch sensor for 2 seconds on any earbud to switch between game & music mode.

Power ON/OFF

Long-press the touch sensor for 10 seconds on any earbud to turn it OFF.

To turn it back ON, put it back in the charging case and close and open the lid.

CALL CONTROLS

Please use the below call control features for compatible mobile devices:

Answer An Incoming Call

Single tap the touch sensor on any earbud to answer an incoming call.

Hang Up Ongoing Call

While on a call, single tap the touch sensor on any earbud to end a call.

Reject An Incoming Call

Double tap the touch sensor on any earbud to reject an incoming call.

Charging The Case

Use the type-C cable to charge the case. The blinking LED indicates that it is charging. The charging case LED stops blinking and remains ON once it is 100% charged.

Low Battery Of The Case

When low on power, you shall hear a notification.

Charging The Earbuds

Place the earbuds in the charging case. The earbuds must make a snap sound when perfectly set in the case cavity.

After placing the earbuds in the charging case, close the lid to start charging.

ENC

Ultrabuds N5 features an Environmental Noise Cancellation (ENC) tech algorithm that negates background noise for a clear hearing experience. ENC need not be manually activated because it is a default mode.

RESETTING THE EARBUDS

Please follow these steps if you see two "TRIGGR Ultrabuds N5" in your Bluetooth device menu on your mobile, or if you can hear music through only one earbud. It happens when the left and right earbuds are not auto-paired with each other.

Step 1

Disconnect the earbuds and remove "TRIGGR Ultrabuds N5" from your list of paired devices.

Step 2

Pull the earbuds out of the charging case and tap the touch sensor on both earbuds for five seconds to clear the pairing data.

Step 3

Place both earbuds back into the charging case. Close the lid and open it again.

"TRIGGR Ultrabuds N5" is now ready for use.

TECHNICAL SPECIFICATIONS

Bluetooth	v6.0
Driver Size (mm)	Ø13mm
Microphone	MEMS Mic
ENC	Yes
Charging Port	Type-C
Charging Time	1.5h
Distance Coverage	≥10m
Low Latency	50ms
Playtime	Up to 40hrs
Controls	Multi-function Touch Controls
Voice Assistant	Yes
Waterproof	IPX4
Weight	35g

SAFETY AND MAINTENANCE

By following these tips, you can ensure the safety of your ears and the longevity of your earbuds.

Use earbuds at a safe volume: Prolonged exposure to loud music can lead to hearing loss. Make sure you use neckband at a safe volume to prevent any damage to your hearing. As a general rule, if someone standing a few feet away from you can hear your music, it's too loud.

Take breaks: Give your ears a break by taking them out every hour or so. This will help prevent any discomfort or pain that can come from prolonged use.

Clean your earbuds: Regularly clean your earbuds with a dry, soft cloth. Avoid using water or any harsh chemicals as this can damage the product.

Store your earbuds properly: Store your earbuds in a clean, dry place to prevent any damage or wear and tear.

Avoid sharing earbuds: Sharing earbuds can increase the risk of ear infections and other health issues. Use your own earbuds and avoid sharing them with others.

Replace worn-out eartips: Over time, the eartips on your earbuds can wear out, which can affect the sound quality and comfort. Replace them as needed to ensure the best possible listening experience.