FIVE YEAR WARRANTY

Confer Plastics Inc. warrants their Leisure Accents Furniture Products to be free from manufacturing and workmanship defects for five years from date of purchase.

In the event of a missing or damaged part, please email us at CustomerService@LeisureAccents.com Upon review of the information, we will contact you to notify you if the part is covered under warranty.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

> Confer Plastics Inc. 97 Witmer Rd North Tonawanda, N.Y. 14120-2421



۲

Complete your backyard by shopping our entire line at

LeisureAccents.com



• Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury! • Check that you have all required parts: Do not attempt to assemble if any parts are missing. Call 800-635-3213 or visit www.LeisureAccents.com for assistance.








video

LEISURE ACCENTSTM **30" TABLE By Confer Plastics**


ASSEMBLY MANUAL

30" TABLE


If missing parts - Toll free U.S./Canada - 800-635-3213 or www.LeisureAccents.com



ASSEMBLY:



1. Place the split legs into the bottom of the full leg and tap into place with a rubber mallet



3. Place the table top upside down such that you can see the bottom of the table. Position the spearheads over the receivers. Tap the bottom of the table legs with the rubber mallet to click the table legs into the table top.

Safe Installation

Split Table Leg

AWARNING • Read all of the instructions in this manual before you begin assembly. Failure to do so may result in

faulty assembly and potential injury!

۲

• Check that you have all required parts: Do not attempt to assemble if any parts are missing. Call 800-635-3213 or visit www.LeisureAccents.com for assistance.

Use product for intended purpose only: DO NOT stand on furniture
Double check after installation: Before using the product, after assembly and installation, review instructions and procedures again to make sure nothing has been overlooked

> Questions, problems, missing parts? Call customer service at 800-635-3213 Email CustomerService@LeisureAccents.com Visit our website at www.LeisureAccents.com

> > Retain this manual for future use

۲



2. Tap the top of the split leg into the opening at the top of the full lea

4



4. Stand the table up and tap the table top ensuring that the table legs are secured to the table top.