



Aguilar Musical Instruments LLC
599 Broadway, 7th fl.
NY, NY 10012
www.aguilaramp.com



DB 599

The DB 599 bass compressor gives bassists the ability to control their dynamics in a simple and compact format. Tailored around the specific needs of bass players, the DB 599 utilizes musically appropriate compression ratios and attack / release parameters to make dialing in your compressed tone a breeze. Simply add in the desired amount of compression with the COMP knob, use the GAIN control to adjust your volume, and take your bass sound to the next level – that's it!

Features:

- Simple two-knob interface
- Bass appropriate compression ratios and attack / release parameters that sound natural and musical
- Studio-quiet with no artifacts
- 9-volt power supply required

Owner's Manual

Manual Version 1.0

I. Functions

COMP: Controls the amount of compression. For more compression, turn clockwise, for less turn counter clockwise. At it's furthest left, your signal is uncompressed.

GAIN: Controls the amount of make-up gain. As you turn up the COMP control your overall output will decrease. Use the GAIN control to add back lost output level.

ENGAGE: Toggles between on and off. The blue LED indicates that the effect is on.

◁ : denotes ¼" input and output jacks. The input jack is located on the right-hand side panel and labeled with an arrow pointing towards the pedal. The output jack is located on the left-hand side panel and it is labeled with an arrow pointing away from the pedal.

DC: This is a standard 2.1mm DC jack. The center terminal polarity is negative.

II. Specifications:

Current consumption:.....6.5mA

Input impedance:1MΩ (Effect On)

Output impedance:600 Ω

External DC Power:9-10VDC, center terminal negative

Dimensions: 3.65" x 1.5" x 1.25"

III. Warranty Information

The DB 599 is covered under limited warranty against defects in materials and workmanship for a period of 3 years. This warranty is non-transferable. The warranty period starts from the date of purchase from an authorized Aguilar dealer. Please retain your sales receipt as it is necessary to obtain warranty service. Before sending your unit to Aguilar for repair, you must receive a return authorization number from us. Please contact us via email (techsupport@aguilaramp.com). Do not send any products to us without first receiving a return authorization from Aguilar.

You are responsible for all shipping charges. You must ship the unit to us freight prepaid. We will return the unit to you freight collect. Aguilar Musical Instruments LLC is not responsible for shipping damage, either to or from our service center. Claims must be filed with the carrier. The only company in the USA authorized to perform work under this warranty is Aguilar Musical Instruments LLC of New York, NY.

Warranty service outside the USA: Warranty Service may be different in your country. Please contact the Aguilar distributor in your country for terms and procedures.

IV. Environmental Protection



This symbol means that used electrical and electronic equipment (WEEE) should not be disposed of with household waste. Please contact your local authority or retailer for further information on nearest WEEE collection center and recycling advice.