


Matching Remote Control

1. With machine OFF, press Topspin and Backspin buttons at the same time. You should observe flashing of SPIN lights.




2. On remote control press Height Up and Topspin buttons at the same time. You should observe a change in the flashing of SPIN lights. If you do not observe a change in the flashing SPIN lights, press the Topspin and Backspin buttons at the same time. This was the procedure on early models.



3. Press the On/Off button on the remote control...



4. A code should appear in the Speed and Feed windows. The code is different for different remotes.



5. Press the On/Off button at the panel. This will turn the panel OFF.



6. Press the On/Off button on the remote. If the machine turns on, the matching is successful.

