



Goal Locking (6'x4')

COMPONENT CHECKLIST AND ASSEMBLY INSTRUCTIONS





SAFETY INSTRUCTIONS

- 1. Always check the goal post and net for defects before use and replace damaged parts.
- 2. Do not use goal with faulty parts.
- 3. The goal must always be secured to the ground. Weight to be used on hard surface, ground anchors on grass.
- 4. Never climb on the or the goal frame.
- 5. The goal must never be used without the net fitted.

Please adhere to the safety instruction at all times.

ASSEMBLY INSTRUCTIONS

1. Assemble the base first.

View 2

- 2. Assemble the cross bar and uprights.
- 3. Fit the cross bar and upright assembly to the base.
- 4. Assemble the tension bar items 8 & 9 together.
- 5. Fit the tension bar assemblies to the goal. It is important that the tension bar is fitted into
- the bottom of the goal first, then bolt them to the upper frame.
- 6. Fit the net by wrapping the net round the post and clipping on the inside. Colored cord denotes top of the net.
- 7. Ensure the posts are upright and the cross bar is level before securing to the ground with the anchors.

INFORMATION

- 1. When the goal is not being used, dismantle and store in a secure area.
- 2. Not suitable for children under age of 3 years due to small parts i.e. quick clips and length of cord.
- 3. It is recommended that the goal is assembled by an adult.

If you need any further assistance or to see an assembly video, please visit www.footballflick.com