



## DIY WiFi Setup

**Basic process:** exit out of the app when it's booting up and you'll have a prompt to connect to WiFi. Once connected, reboot!

### Step-by-step:

1. Plug the USB stick for the wireless keyboard and mouse into the player.
2. Flip the switch to ON for both the keyboard and the mouse to power them on.
  - a. Please note that a cabled keyboard and mouse does work as well.
3. Make sure your player is connected to your TV via HDMI and that the TV is tuned to the corresponding HDMI input (i.e. HDMI 1).
4. Power on the player (or for the Lite "stick" style player, plug it into power).
5. SOON after starting up (on the white "Playr" screen), hit CTR+ALT+S to exit out of the signage app as directed at the bottom.
6. At this point you may now see a prompt for connecting to your WiFi. If not, then click on the time at the lower-right corner of the screen. Inside you will see a line that says "no network." If you click on that you can select your WiFi network and type in the password.
7. Disconnect your keyboard/mouse and then reboot your player (turn it off and back on) and it will begin playing over WiFi!
8. If your player hasn't been registered yet then you will see steps on-screen for how to connect it to your account.

**PLEASE NOTE:** You may have noticed earlier that if you let your player start-up completely that it will show a screen with WiFi information that appears as though you can connect to your WiFi from there. For our purposes that method does not work, so please use the above procedure to get connected.

Thank you!

SmartSign2go