ASSEMBLY INSTRUCTIONS


DINING TABLE



WF309714


IMPORTANT NOTE:


- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DON NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE SET IS FULLY SET-UP.



CARTON CONTENT

WF309714:












TABLE PART LIST FOR ONE					TABLE HARDWARE LIST FOR ONE				
NO	DESCRIPTION	SKETCH	QTY	NO	DESCRIPTION	SKETCH	QTY		
A	TABLE TOP WITH APRON		1 PC	1	WOOD DOWEL M8 x 30 MM		4 PCS		
В	TABLE LEG 1		2 PCS	2	JCBC SCREW M6 x 40 MM		8 PCS		
С	TABLE LEG 2		2 PCS	3	JCBC SCREW M6 x 50 MM	((((((((((((((((((((((((((((((((((((((8 PCS		
D	STRETCHER		1 PC	4	JCBC SCREW M6 x 70 MM	((((((((((((((((((((((((((((((((((((((2 PCS		
Е	TABLE LEG DOWN		2 PCS	5	SPRING WASHER M6	(a)	18 PCS		
					FLAT WASHER M6 x 13 MM	0	18 PCS		
					WOOD BUTTON 14.5MM	\bigcirc	10 PCS		
				8	ADJUSTABLE M6 x 23MM		4 PCS		
				9	ALLEN KEY M4		1 PC		

03-06










ASSEMBLY INSTRUCTIONS

DINING CHAIR




WF309719


IMPORTANT NOTE:

- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DON NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR SET IS FULLY SET-UP.

CARTON CONTENT

WF309719:











CHAIR PART LSIT FOR ONE					CHAIR HARDWARE LIST FOR ONE					
NO	DESCRIPTION	SKETCH	QTY	NO	DESCRIPTION	SKETCH	QTY			
A	CHAIR BACK		1 PC	1	JCBC SCREW M6 x 35 MM	<i>(((((((((((((((((((((((((((((((((((((</i>	2 PCS			
В	CUSHION SEAT WITH APRON		1 PC	2	JCBC SCREW M6 x 60 MM	((((((((((((((((((((((((((((((((((((((4 PCS			
С	CHAIR LEG		2 PCS	3	JCBC SCREW M6 x 80 MM		4 PCS			
				4	SPRING WASHER M6		10 PCS			
				5	FLAT WASHER M6 x 19 MM	0	10 PCS			
				6	ALLEN KEY M4		1 PC			
				_						

