



**RV ELECTRONICS**  
MANUFACTURER OF RECREATIONAL VEHICLE ACCESSORIES



CARAVAN  
CAMPER TRAILER  
4WD'S  
RV'S  
TRADIES

# PROGRAMMABLE LED WATER LEVEL INDICATOR

## SINGLE TANK - FITTING INSTRUCTIONS

FOR USE WITH RV ELECTRONICS  
PROGRAMMABLE SENDER PROBES ONLY.  
SUITABLE FOR PLASTIC AND METAL TANKS.



**STEP 1: Single gauge example:** Once removed you will see a 6 position DIP switch and a set button on the back of the gauge board. (See figure)

**STEP 2:** The single tank diagram shows only one plug and only position 3 and 4 are needed. DIP position 3 is used to set empty and DIP position 4 is used to set full.

**STEP 3:** To set empty, slide the DIP switch in position 3 to on, press and hold **both** front TEST button **and** the rear SET button at the same time until the 2 bottom LEDs on the gauge flash. (Make sure you return the DIP switch to off when done.)

**STEP 4:** To set display full, fill the water tank to full, slide the DIP switch in position 4 to on, press and hold **both** front TEST button **and** the rear SET button at the same time until the top full LED on the centre gauge flashes. (Make sure you return the DIP switch to off when done.)

If you make a mistake or want to reset a tank to the factory settings, simply slide both the empty and full DIP switches to on for the tank you wish to reset. (DIP position 3 + 4) Press and hold the TEST **and** SET buttons for 5 - 10 seconds until all the gauge LEDs flash on and off.



Use this outline as your cutting template

## WARNING

**DO NOT UNDER ANY CIRCUMSTANCES USE THIS WATER LEVEL INDICATOR IN FLAMMABLE LIQUIDS.  
THIS PRODUCT IS FOR USE IN WATER ONLY.**

MADE IN AUSTRALIA BY  
**RV ELECTRONICS PTY LTD**

1 ARDTORNISH STREET, HOLDEN HILL, SA 5088  
(08) 8261 3500 | [info@rvelectronics.com.au](mailto:info@rvelectronics.com.au) | [rvelectronics.com.au](http://rvelectronics.com.au)