AUTOMATIC 3 HANDS WITH DATE



Winding the mainspring

Automatic winding watch can also be hand winded by turning the crown clockwise in the "N" position. Wind 15-20 times and it will start to move naturally after shaking slightly.

SETTING THE TIME

- 1. Pull the crown out to the position 2.
- 2. Turn the crown to set hour and minute hands.
- 3. After the time has been set, push the crown back to the normal position

SETTING THE DATE

- 1. Pull the crown out to the position 1.
- 2. Turn the crown counter-clockwise to set the date.
- *If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
- 3. After the date has been set, push the crown back to the normal position.

