

## JAPAN AUTOMATIC 2 HANDS WITH SMALL SECOND AND DATE

# AVI-8

### WINDING THE MAINSPRING

1. Wind 15-20 times by turning the crown clockwise in **Normal Position** before setting the time/date. It will start to move naturally after shaking slightly.

### SETTING THE TIME

1. Pull the crown out to the **Position 2**.
2. Turn the crown to set hour and minute hands
3. Push the crown back to **Normal Position**

### SETTING THE DATE

1. Pull the crown out to the **Position 1**.
2. Turn the crown counter-clockwise to set the date
3. After the date has been set, push the crown back to the **Normal Position**

\*Take AM/PM into consideration when setting the hour and minute hands to the desired time

### TIPS

\*If the date is set between the hours of around 9:00pm and 4:00 am, the date may not change on the following day

