

JAPANESE QUARTZ 3 HANDS WITH DAY AND DATE

AVI-8

SETTING THE TIME

1. Pull the crown out to the 2nd position when the second hand is at the 12 o'clock position.
2. Turn the crown to set the hour and minute hands.

Take AM/PM into consideration when setting the hour and minute hands to the desired time.

- When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.


3. Push the crown back to the normal position.

SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown to set the date and the day of the week.
Do not set the date and day of the week between 9:00PM and 4:00AM.
3. Push the crown back to the normal position.

Tips :

1. When the date and the day of the week changes during daytime, it happens when AM/PM is wrongly set.
 2. Advance the hour hand by 12 hours.
-



AVI-8

POWER DEPLETION WARNING FUNCTION

When the battery nears its end, the second hand moves at two-second intervals instead of the normal one-second intervals. In that case, have the battery replaced with a new one as soon as possible.

- The watch remains accurate while the second hand is moving at two-second intervals.

Note: The availability of this function is different depending on the caliber.
