2.3W Waterproof Landscape Light


User Manual

O1/WARNING

Please read all safety precautions and installation instructions carefully before installing the fixture:


- 1. Please check and make sure there is no sign of physical damage to the product when unpacking. Do not use damaged products.
- 2. Turn off power before attempting any installation or servicing.
- 3. Risk of fire or electric shock, installation of this product requires knowledge of the electrical systems, if not qualified, do not attempt installation. Contact a qualified electrician.
- 4. Please handle gently to make sure the lifespan and appearance.
- 5. Make sure all gaskets are positioned correctly with no gaps to prevent power leakage.
- 6. The voltage of this LED deck light is 12 to 36V. Please check that supply voltage matches the voltage marked on the label prior to connecting to supply leads.

02 / PRODUCT DIAGRAM




03 / INSTALLATION

Step 1. Loosen the three screws on the cover by the hex key in the accessories.




Step 2. Attach the triangle sticker to the mounting position. Drill three holes according to the sticker and lightly tap the plastic anchors into the holes with a hammer (not included).


Step 3. Align the holes on the fixture with three anchors in holes. Attach the fixture to the mounting position with three screws in the accessories




Step 4. Use the wire nuts to connect the wires.



Step 5. Make sure the waterproof gasket is in a good position. Close the cover and tighten the screws.



Step 6. Fill the gap between the fixture and the wall with sealant.



04/WARRANTY

LEONLITE warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. If the product has been misused, damaged by accident or in any other way of improper use, this warranty becomes void.

