



SURVIVOR FILTER

2-Pack Sports Water Bottle Care and Use Instructions



CAUTION

- This bottle is not designed for hot liquids.
- Check product regularly for proper function.
- Replace immediately if damaged.
- Do not microwave or freeze.
- Do not overfill the bottle.
- Do not use any cleaning products containing bleach, chlorine, abrasives and/or other harsh chemicals.

USAGE RECOMMENDATIONS



CLICK TO OPEN



PUSH DOWN TO CLOSE



FILL WITH ICE



FILL WITH FRUIT, VEGETABLE OR FRESH HERBS



CLEANING INSTRUCTIONS


- Wash thoroughly before first use.
- Rinse lid immediately after each use.

DISHWASHER

1. Place the lid on the top-rack of the dishwasher.
2. Run dishwasher as normal.

HANDWASHING

1. Disassemble and wash the body, fruit infuser and lid separately with warm water and a mild detergent.
2. For best cleaning results, use a bottle brush to scrub the inside of the lid and bottle gently.
3. Always store the bottle with lid removed to allow the parts to dry completely.



DISHWASHER SAFE
TOP RACK ONLY

LIFETIME WARRANTY

We go to great lengths to create superior products and back all our products with a Lifetime Guarantee and Warranty. If you are not 100% satisfied with your purchase, we got you covered.

