

Take the base (1), turn the hooks 180 degrees. Next, with the help of screws (a), nuts (b) and two keys (c), screw it to the guide base and tighten the other screws (a) See Pic. 1.



To be used for its intended purpose only and under the direct supervision of an adult! All the responsibility for children's injuries received during games on the furniture lies on adults watching after them.

Always be vigilant during children's games!