



CARE & CLEANING

# INSTRUCTIONS

## General Cleaning

- Scrub with LuxCraft Poly Brite cleaner using a scrubbie or plastic bristled brush.
- A soft bristled toothbrush can be used to clean spaces that are hard to reach.
- To remove surface dust, hose furniture down with cold, clear water.

## Deep Cleaning

- A pressure washer can be used on the lightest setting to deep clean your furniture.
- It is not recommended to use more than 1,500psi.
- Keep the tip of the pressure washer at least 10-12 inches from the furniture to prevent damage.

## Stain Chart

Stain	Recommended Cleaning Process
Pencil Marks	Saturate the stain with Poly Brite, then rinse with water.
Ink/Marker	Saturate the stain with Poly Brite, then rinse with water. For tough stains, pretreat area with WD-40®, wiping clean before using Poly Brite.
Grease or Oil Stain	Saturate the stain with Poly Brite, then rinse with water.
Embedded Dirt	Saturate the area with Poly Brite, then scrub with a soft bristled brush, and rinse with water.
Wine	Saturate the area with Poly Brite, then scrub with a soft bristled brush, and rinse with water.
Chewing Gum	Coat WD-40® lubricant or equivalent over the area. Gently pry up on any potentially hard articles slowly with a plastic putty knife. Utilize a soft brush and acetone solvent to remove any fine debris and clean out any crevasses. Rinse area with fresh water.
Bird Droppings	Saturate the area with Poly Brite, then scrub with a soft bristled brush, and rinse with water.
Stains and Scuffs	A Magic Eraser™ may be used for stubborn marks.
Iron and Rust	For tough stains from contact with iron, scrub with Iron Out™.

*If using alternative cleaning solutions than those outlined above, it is recommended to test the solution on an inconspicuous area, to make sure it does not harm the surface.*