

Thank You!



**Club**  
KEYBOARD

[clubkeyboard.com](http://clubkeyboard.com)

# Installation and Operating Instructions

The Club Keyboard is plug and play, simply plug it into a Windows PC and it will be ready for use!

Flyover (O)

Aerial Preview of Hole

Hide Objects (B)

Hide objects blocking view

Pin (P)

Show pin marker

Clear Tracers (F1)

Clear tracers on range

Club | Drop (K/I)

Club Up/Down

Putter (U)


Select Putter

Aim (←→)

Aim Right or Left

Aim (↑↓)

Aim Forward/Backward



**Light switch (LED version only)** - Turns LED lights on or off. Note, the keyboard is always on when plugged in via USB, this switch only turns lights on and off. The keyboard can be used with the lights on or off.

Mulligan (Ctrl+M)

Rewind Shot

Target (J)

Shot cam  
View target location

FFW (Space Bar)

Fast forward shot

Aim Point (F3)

View aim point/green

Score Card (T)

View score card

Go To Ball (G)

View ball location

Heat Map (Y)

View green elevation  
heat map

If you have any questions about your new keyboard, please visit our website or send an email to [support@clubkeyboard.com](mailto:support@clubkeyboard.com)

[clubkeyboard.com](http://clubkeyboard.com)