

Thank You!



Club
KEYBOARD

clubkeyboard.com

Installation and Operating Instructions

The Club Keyboard is plug and play, simply plug it into a Windows PC and it will be ready for use!

Flyover (O)

Aerial Preview of Hole

Heat Map(Y)

View green elevation heat map

Map Zoom +/- (Q/W)

Zoom in or out on the mini map

Club | Drop (K/I)

Club Up/Down

Putter (U)


Select Putter

Aim (←→)

Aim Right or Left

Aim (↑↓)

Aim Forward/Backward



Mulligan (Ctrl+M)

Rewind Shot

Target (J)

Shot cam
View target location

Pin (P)

Show or hide the pin indicator

Aim Point (F3)

View aim point/green

Score Card (T)

View score card

Fast Forward (Space)

Hold to fast forward ball roll for slow moving balls

Reset Aim (A)

Reset aim to original position

Light switch (LED version only) - Turns LED lights on or off. Note, the keyboard is always on when plugged in via USB, this switch only turns lights on and off. The keyboard can be used with the lights on or off.

If you have any questions about your new keyboard, please visit our website or send an email to support@clubkeyboard.com

clubkeyboard.com