



Microlight Headset Adapter to Alphatec or Flycom Intercom

Part No. MM016D

Converts MicroAvionics or Lynx microlight headset connector to fit 6.3mm jack for Alphatec or Flycom Intercom.

1. Connect headset to adapter.
2. Connect the adapter to twin single jack intercom
3. Turn intercom power on.

Setting up microphone for direct or amplified signal.

a. Inside the adapter, there is a red link shorting 2 pins, this can be connected to 2 of the 3 pins. Either the inner 2 pins or the middle and outer pin. Outer and middle set the microphone as direct, un-amplified connection. Inner 2 pins connect the microphone as amplified.

If you use microphone amplified, then you can also read section 'b' below to set the microphone amplification.

b. If using microphone amplified connection, as in section 'a'. There is a microphone gain dial inside the adapter, this should be adjusted to the user's requirements. To adjust this first remove the cover to the adapter and locate the gain adjuster. Turn the volume on the partner's headset to the specified level for there own voice and now adjust the small gain adjuster in the adapter until the partner's headset hears you to a satisfactory volume level.