



2L Bento Lunch Box

CARE AND USAGE GUIDE

- Secure clips
- Airtight lid seal to keep lunch fresh
- Two snack compartments
- Removable hinged lid
- Ideal for meal prep
- Microwave safe, remove lid to microwave
- All parts are top rack dishwasher safe for easy clean up
- Microwave safe, remove lid to microwave
- Freezer safe
- BPA free



USAGE

- To remove dividers, gently twist divider. To connect, push firmly down on small divider. Angle large divide diagonally and gently twist into position.
- Microwave reheat only, remove lid to microwave



WARNING

- Overheating of foods high in oils, fats or sugar may cause product to melt. If the product melts with hot contents, there is risk of burn injury. Use oven mitts to prevent injury.
- Never cook popcorn in this product.
- Not suitable for children under 36 months old.
- If product is damaged, discontinue use.

Please read and follow these usage and safety guidelines to maximise the life of your Decor product