



Double Wall Reusable Durable Tritan™

CARE AND USAGE GUIDE

- Medium 340ml | 11.5fl oz
- Barista friendly standard size
- Made with Premium Durable Tritan™
- Easy pop open, pop close spill resistant lid
- Non slip silicone grip
- Cool touch double wall design



USAGE

- Use warm soapy water to thoroughly wash cap and base before use and after each use.
- Separate all cup parts before washing. Inner cup can be removed. Pull top disk of lid firmly from back edge to separate into two parts.
- Dishwasher safe.
- Place lid in open position before placing lid on base.
- Use with the lid on only.
- Suitable for hot & cold drinks



WARNINGS

- Never overfill cup and ensure lid is properly fitted to base.
- Contents may be hot. To prevent injury allow very hot liquid to cool to drinking temperature before closing lid.
- Do not carry product containing liquids in bags in case of accidental opening.
- Not suitable for freezer or microwave use.
- Not suitable for children under 36 months old.
- If product is damaged, discontinue use.