



# Double Wall Reusable Tea Infuser

## CARE AND USAGE GUIDE

- Medium 350 ml | 17 fl oz
- Made with premium borosilicate glass
- Drop in stainless steel tea infuser
- Cool touch glass



## USAGE

- Separate all parts before washing. Use warm soapy water to thoroughly wash cap and base before use and after each use.
- Hand wash only.
- Take care when removing tea infuser basket from bottle
- Recommend pouring liquid into heat proof mug/cup



## WARNINGS

- Never overfill cup and ensure lid is properly fitted to base.
- Contents may be hot. To prevent injury allow very hot liquid to cool to drinking temperature before closing lid.
- Do not carry product containing liquids in bags in case of accidental opening.
- Glass is breakable and must be handled with care to avoid personal injury or property damage
- Do not use if glass is chipped, cracked or has significant scratches
- Not dishwasher, freezer or microwave safe.
- Not suitable for children under 36 months old.
- If product is damaged, discontinue use.