

CARE AND USAGE GUIDE

- 500ml | 17 fl. oz
- Crystal clear odour resistant Tritan™
- Lightweight & durable
- Easy open drink spout
- Dishwasher friendly stickers
- Dishwasher safe.
- BPA free



USAGE

- Use warm soapy water to thoroughly wash cap and base before use and after each use.
- Straw can be detached. Décor recommends using a straw cleaner to clean product components thoroughly
- Suitable for cold liquids only



WARNINGS

- Never overfill cup and ensure lid is properly fitted to base
- Do not carry product containing liquids in bags in case of accidental opening.
- Not suitable for freezer or microwave use.
- Not suitable for children under 36 months old.
- If product is damaged, discontinue use.