

GARDEN RANGE

CARE AND USAGE GUIDE

Keep your garden organised with the Decor Garden Range, this clean and simple design has superior features and durable long lasting quality.



Please read and follow these usage and safety guidelines to maximise the life of your Decor product

USAGE

- Self-watering in-built water reserve
- Stores up to 4 weeks of water (depending on plant)
- Ventilated floor helps aerate root systems
- Strong rollover rim makes pot easy to handle



WARNING:

- To prolong the life of your garden range, avoid consistently leaving products in directly sunlight.
- If product is damaged, discontinue use

CARE:

To clean your product, simply wipe down with a damp cloth