



# Solid Wood 2x3 Cornhole Board Set

## INSTRUCTION MANUAL



PLEASE KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

If you have any concerns with your product please visit our website [victorytailgate.com](http://victorytailgate.com) for fastest service. Please have a copy of your receipt of purchase. For any technical support or warranty issues please contact Victory Tailgate at 1-888-577-4460 or e-mail us at [info@victorytailgate.com](mailto:info@victorytailgate.com)

## Limited 90-Day Victory Tailgate Warranty

All Victory Tailgate games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any Victory Tailgate game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the Victory Tailgate game. This will void any and all Victory Tailgate warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-888-577-4460 or email us at [info@victorytailgate.com](mailto:info@victorytailgate.com)

**IMPORTANT NOTICE!** Please contact us before returning the product to the store.

## Warnings



Not for use by children without adult supervision. This is not a child's toy. Adult supervision is required for children playing this game. Please read instructions carefully.



Be sure to check out all the exciting games Victory Tailgate has to offer. Visit our web site at:

[ESCALADESPORTS.COM](http://ESCALADESPORTS.COM)

[VICTORYTAILGATE.COM](http://VICTORYTAILGATE.COM)



Bag Toss






Indoor Games



Outdoor Games

# Parts List



To order replacement parts please call our customer service department.




VICTORYTAILGATE.COM | 1-888-577-4460  
INFO@VICTORYTAILGATE.COM  
©2019 VICTORY TAILGATE, LLC.  
ALL RIGHTS RESERVED.

**NOTE:**

When calling customer service please have the model number available. This number is printed on the upper right hand of the cover page of the manual.

# Playing Instructions



## **GAME SETUP:**

1. Playing Area – Select an open area that provides approximately 18 ft. (approx. eight paces apart) between the two foul lines (front of the Bean Bag Boards). Allow children to set the distance with their own stride. The width of the court depends on the skill level of the players.
2. Play is between two players or teams. One member from each team will stand next to each board.

## **RULES OF THE GAME:**

- Object of the Game – First Player/Team to reach 21 points wins!
- Game Play - For the first round, decide Player 1 and/or Team 1 by tossing a coin, or some other suitable method. For following rounds, the team scoring the highest points in the previous round is the first to toss in the next round.
- Each round consists of one person (either Player 1 or Player 1/Team 1) tossing bean bags. Play continues alternating Player/Team until each player has tossed their bags.
- Bean bags may be tossed in any way the player chooses, as long as they are tossed individually.
- Players must not step across the foul line (front edge of the Bean Bag Board) during a throw, or that throw does not count.
- Point Values (based on difficulty level) are as follows:
  - A bag thrown through the hole earns 3 points. A bag that lands on the board earns 1 point.
  - Subtract the low score from the high score for each round of play. For example: Team A has 1 bag in the hole and 2 bags on the board, for a score of 5 points. Team B has two bags on the board, for a score of 2 points. Team A (5 points) – Team B (2 points) = Team A (3 points). Team A receives 3 points for that round of play.
- No Score - Bean bags bounce off the ground do not count in scoring.
- To Win – There are alternatives for declaring a winner: 1) the winning team must lead by at least five points; or 2) requiring an exact score to win. If a round's score would put a team over 21, that round's score is not used.
- Hint: You can knock your opponent's Bean Bags off the board.