




## **CP Plus Functions**



- a) boiler Hot water generator is on. Icon flashes until desired temperature is reached.
- **b)** eco Water temperature is  $104^{\circ}F$  (40° C)
- c) hot Water temperature is  $140^{\circ}F$  (60° C)
- boost Boiler content is heated quickly (boiler priority) for up to 40 minutes. The water temperature is then kept at the higher level (about 144° F (62° C) for two subsequent heating cycles. When the water temperature is reached, the room is heated again.





## **CP Plus Functions – Cont.**

Set clock to current time

## Set time switch

Set a start time and end time for room temperature, water temperature, energy mode and fan speed set points.

## Settings

Index - Show version number of connected device Bright - Adjust backlighting Lang - Adjust language 12-24h - 12/24 hour mode Temp – °F or °C Offset – Calibrate temp offset Pr set – Factory reset



Select fan speed

 $\ensuremath{\text{OFF}}$  – Fan is switched off (If furnace mode OFF)

- a) VENT Circulating air (If furnace mode OFF)
- b) ECO Low fan speed
- c) HIGH High fan speed
- BOOST Fast room heating. Available if the difference between the selected and current room temperature is >18° F (10° C)