

NeoBuds Pro

True Wireless Stereo Earbuds with Active Noise Cancellation



— Manual —

JP 1. オン/オフ

オン/オフ



・ケースが開くと電源がオンになります

インジケータ



・ケースにいれて閉じると電源がオフになります

2. ペアリング



インジケータ

- イヤホンケースに入れます。
- ケースのボタンを約3s押してください。LEDが左から右に1つずつ順に循環して点灯します。
- 接続設定するデバイスで「EDIFIER NeoBuds Pro」を選択します。

初回のペアリング

- ケースを開きます。LEDが左から右に点滅します。
- 接続設定するデバイスで「EDIFIER NeoBuds Pro」を選択します。

注：
後の使用のために、イヤホンは前回使用したデバイスに自動接続します。

3. リセット/左&右の接続



インジケータ

- イヤホンケースに入れます。
- ケースのボタンを3回押して、左右の接続に入り、ペアリング記録をクリアします。
- LEDが側面から真ん中に1つずつ順に循環して点灯します。

4. コントロール

左のタッチパネル 右のタッチパネル



コールの応答/終了:

x2

モードの切替:

x2

ゲームモードオン/オフ:

x3

コールの応答/終了:

x2

再生/一時停止:

x2

次の曲:

x3

注:

- ダブルイヤホンモードスイッチ：ハイノイズキャンセルモード&アンビエントサウンドモード。
- シングルイヤホンモードスイッチ：通常モード&アンビエントモードのみ。
- Edifier Connect アプリによるカスタマイズ管理。
- 画像は参照用です。

詳細情報は当社ウェブサイトをご覧ください:

www.edifier.jp



@Edifier Japan



@edifier.japan



@EDIFIER JAPAN【公式】

モデル: EDF200051

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

www.edifier.com
© 2021 Edifier International Limited. 禁無断転載
印刷: 中国

ご注意

本書に記載の情報は、技術の改良、システムのアップグレードなどのため、予告なく変更されることがあります。EDIFIERの製品は、さまざまな用途を考慮してカスタマイズされます。本書の図や写真は実際の製品と異なることがあります。その場合、v実際の製品設計が優先します。



• Power ON when the case is opened



• Power OFF when placed in the case and the case is closed

2. Pairing



1. Placed in the case.
2. Press and hold the button on the case for around 3s. LEDs will be lit one by one from left to right in a circulating pattern.
3. Select "EDIFIER NeoBuds Pro" in your device setting to connect.

1st Pairing

1. Open the case. LEDs will blink from left to right.
2. Select "EDIFIER NeoBuds Pro" in your device setting to connect.

Note:


For subsequent use, the earbuds will auto-connect to device used last time.

3. Reset/Left & Right connection



1. Placed in the case.
2. Press 3 times the button on the case to enter left & right connection and to clear pairing records.
3. LEDs will be lit one by one from sides to center in a circulating pattern.

4. Controls



Accept/end a call:

x2

Mode switch:

x2

Game mode on/off:

x3

Accept/end a call:

x2

Play/pause:

x2

Next track:

x3

Note:

1. Both Earbuds mode switch: High noise cancellation mode & ambient sound mode.
2. Single Earbud mode switch: Normal mode & ambient sound mode only.
3. Customized controls via Edifier Connect App.
4. Images are for illustrative purposes only and may differ from the actual product.

For more information, please visit our website:

www.edifier.jp



@Edifier Japan



@edifier.japan



@EDIFIER JAPAN【公式】

Model: EDF200051

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

www.edifier.com

© 2021 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.