

WH500

Wireless On-Ear Headphones





JP 1.オン/オフ



電源ボタンを2s長押しします。



1. 電源を切ると、電源ボタンを6s長押しします。状態ライトは青色で点滅します。
 2. 接続設定するデバイスで「EDIFIER WH500」を選択します。

初回のペアリング

- ヘッドフォンがオンになったら、Bluetoothペアリングに自動的に入ります。
 状態ライトは青色で点滅します。
- 2. 接続設定するデバイスで「EDIFIER WH500」を選択します。

注:

- 2回目の使用以降は、ヘッドホンは前回使用したデバイスに自動的に接続されます。
- 2. デュアルデバイス接続:デバイスに接続した後、ヘッドフォンを再起動して、 Bluetoothペアリングに入り、2番目のデバイスに接続します。¹番目のデバイス から再度ヘッドフォンを手動でペアリングし、デュアルデバイス接続を完了さ せます。

3. リセット





- へッドフォンがオンになったら、「↓」と ↓」を同時に6s長押しします。
- 2. ステータスライトは、リセットが完了するまで白色で点滅します。

 ヘッドフォンがリセットされたら、Bluetoothペアリングモードに自動的に 入ります。

4.状態ライト







注:

サウンドモードは「音楽モード」と「ゲームモード」で切り替わります。
 画像は参照用です。

詳細情報は当社ウェブサイトをご覧ください:

www.edifier.jp







յրո

@Edifier Japan

@edifier.japan

@EDIFIER JAPAN【公式】

モデル: EDF200095 Edifier International Limited P.O. Box 6264 General Post Office Hong Kong

www.edifier.com © 2022 Edifier International Limited. 禁無断転載 印刷:中国

ご注意: 本書に記載の情報は、技術の改良、システムのアップグレードなどのた め、予告なく変更されることがあります。 EDIFIERの製品は、さまざまな用途を考慮してカスタマイズされます。 本書の図や写真は実際の製品と異なることがあります。その場合、実際 の製品設計が優先します。

EN 1. Power ON/OFF



Press and hold the power button for 2s.

2. Pairing



1. When they're power off, press and hold the power button for 6s. The status light blinks blue.


- 2. Select "EDIFIER WH500" in your device setting to connect.

1st Pairing

- 1. Once the headphones are power on, they will enter Bluetooth pairing automatically. The status light blinks blue.
- 2. Select "EDIFIER WH500" in your device setting to connect.

Note:

- 1. For subsequent use, the headphones will auto-connect to device used last time.
- 2. Dual-Device Connection: After connected to a device, restart and enter Bluetooth pairing to connect the second device. Then manually re-pair the headphones again from the first device to complete Dual-Device connection.



- Indicator
- 1. When the headphones are power on, press and hold the **#** and **#** " at the same time for 6s.
- 2. The status light blinks white until reset is completed.
- 3. Once the headphones are reset, they enter pairing mode automatically.

4. Status Light



Bluetooth Status

- **Blue LED blinks**
- \mathbf{x} Blue LED on for 3s
- Blue LED blinks twice for every 5s for 10mins

Battery Status

- Red LED blinks twice every 5mins
- 🛃 Red LED on
- 📕 LED off

5. Controls





Note:

- 1. Sound Mode switch between "Music Mode" & "Game Mode".
- 2. Images are for illustrative purposes only and may differ from the actual product.

For more information, please visit our website:



Model: EDF200095 **Edifier International Limited** P.O. Box 6264 **General Post Office** Hong Kong

www.edifier.com © 2022 Edifier International Limited. All rights reserved. Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications.

Pictures and illustrations shown on this manual may be slightly different from actual product.

If any difference is found, the actual product prevails.