


There is no necessity to separate the fluid needle lock nut (No.6), guide valve (No.8), air joint (No.19), and fluid joint (No.20).



NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
1	Air Cap	1	9	O-Ring	1	16-3	Ball	1
2	Fluid Nozzle	1	10	Piston Seal	1	17	Spring	1
3	Needle Packing Sets	1	11	Piston Valve	1	18	Fluid Adj. Knob	1
4	Needle Packing Seat	1	12	Fluid Needle Set	1	19	Air Joint	2
5	Spread Adjusting Valve Set	1	13	Fluid Needle Spring	1	20	Fluid Joint	1
6	Needle Lock Nut	1	14	Piston Valve Spring	1	21	Lock Screw	1
7	O-Ring	1	15	3.5E-Ring	1	22	Gun Body	1
8	Guide Valve	1	16	Fluid Adj. Guide	1	23	Dust Seal	1