


DELLA®



Remote Control Discontinued Model 02



Instruction Manual
Installation and Operation Guide


Before Using

Remote Control (Inserting Battery)

1. Remove the back cover.
2. Insert 2 LR03 AAA 1.5 v batteries into the remote control.
3. Reinstall the back cover.




- Do not use rechargeable batteries.
- Replace the old batteries with new ones of the same type.
- Do not dispose batteries as unsorted municipal waste.




Before Using

Remote Control



Basic Operation



Power ON


Press  .

- The air conditioner will start operating.

Power OFF

Press  .

- The air conditioner will stop operating.




Select Operation Mode

Press  to select operation mode.



- It may takes a few minutes for the air conditioner to switch between modes.
- During Heat mode, the air conditioner can automatically activate defrost cycle, which is essential to remove frost on the condenser for heat exchange function. This procedure usually last for 2 - 10 minutes. When defrosting, indoor unit fan will stop operating. Once defrosting is completed, it will resume heat mode automatically.

Basic Operation



Adjust Temperature

Press to adjust temperature setting .

- Temperature setting will adjust by 1°F / 1°C increment for each time the button is pressed.
- Press and hold the buttons to adjust temperature continuously.
- Temperature can only be set between 60°F - 90°F / 16°C - 32°C.


Set Fan Speed

Press to select your desired fan speed.



	Auto	Cool	Dry	Heat	Fan
 Temperature Setting	N/A	60°F - 90°F / 16°C - 32°C	60°F - 90°F / 16°C - 32°C	60°F - 90°F / 16°C - 32°C	N/A
 Fan Speed	All Fan Speed	All Fan Speed	All Fan Speed	All Fan Speed	All Fan Speed

Basic Operation



Adjust Air Flow

Press  to oscillate horizontal flaps.



Press  one more time. → The flaps will stop at the position it was in when you pressed the button.


Press  to oscillate vertical vanes.




Press  one more time. → The vanes will stop at the position it was in when you pressed the button.

QUICK TIPS

- When holding the horizontal flaps in place. It is recommended to hold the flaps in the up most position during cool mode. Vice versa, it is recommended to hold the flaps in the down most position during heat mode.




▪ Cold air tends to sink.



▪ Warm air tends to rise.

Advance Function




Turbo Mode

Using turbo mode can boost the air conditioner performance in a short amount of time.

Press .

- The air conditioner will operate in boosted fan speed.

To stop turbo mode, press  again.



Eco Mode


The air conditioner will operate with maximum energy efficiency.

Press .

- ECO mode is only available when the air conditioner is operating in cool or heat mode.
- The air conditioner will operate in ECO mode for 8 hours and then goes back to normal mode.

To stop quiet mode, press  again.

Advance Function



Timer Function (Shutdown Timer)

Set a timer to automatically turn OFF the air conditioner.

Press when the air conditioner is ON.

Press to set the desired turn off time.

Press to confirm the timer setting.



To cancel shutdown timer, press again.

Timer Function (Start-up Timer)

Set a timer to automatically turn ON the air conditioner.

Press when the air conditioner is OFF.

Press to set the desired turn off time.

Press to confirm the timer setting.

Press , and to select your desired operation mode, temperature setting, and fan speed for when the air conditioner is turn ON.




To cancel start-up timer, press again.

NOTE: Sleep, Display and iFeel buttons are not functional for start-up timer.

QUICK TIPS

- Both the shutdown and start-up timer can be set between 0.5 - 24 hours.

Advance Function



Sleep Mode


In sleep mode, the air conditioner will operate a pre-set program which is suitable during sleep.

Press .


- Sleep mode will operate for 10 hours and then switch back to previously set mode.
- Sleep mode is not available when the air conditioner is operating in auto, dry or fan mode.

Press again to stop sleep mode.

Sleep mode operation



NOTE: This graph is for informational reference only. The actual product may change temperature at a different rate depending on the initial set temperature in sleep mode.




Self Cleaning

Self cleaning function allows the air conditioner to clean the interior parts and helps carry away the accumulated dirt, bacteria, etc. from the indoor evaporator.

Press when the air conditioner is OFF.

- will display on the indoor unit display.
- The self cleaning function will run for 30 minutes, then it will return to the previously operating mode once it is finished.
- It is recommended to operate this function when the indoor ambient temperature is under 86°F / 30°C, and the outdoor ambient temperature is between 41°F - 86°F / 5°C - 30°C.
- It is suggested to run the self cleaning function once every 3 months.
- It is normal that the unit makes some noise during self cleaning process as plastic materials expand and contract with temperature change.


Advance Function




i FEEL Mode

Vicinity sensor function turns your remote control into a portable thermostat that automatically controls the unit to adjust the temperature of the room you are in.

Press  to activate vicinity sensor function.



Press  again to stop vicinity sensor function.




Display ON / OFF

Switch ON / OFF the LED display on the indoor unit front panel.

Press  to turn OFF the indoor unit display.

Press  again to turn ON the indoor unit display.

Advance Function



Anti-Fungus Function

Anti-Fungus function allows the air conditioner to dry the interior parts after you turning off the air conditioner to prevent fungus or mold growth.

Press  the air conditioner is OFF.


- The indoor unit beeps 5 times and the remote control display flashes 5 times indicating the Anti-Fungus function is enabled.
- The next time you turn off the air conditioner after using, the unit will automatically operate in HEAT mode and low fan speed for about 3 minutes before fully turning off.

NOTE:

When Anti-Fungus function is operating, do not turn on the unit before it has completely turned off.

Anti-Fungus function is not functional when shut-down timer is set.

Press  again when the air conditioner is OFF to disable Anti-Fungus function.




Health Function

Health function includes negative ion, electrostatic precipitation, and PM2.5 removal.

Press  when the unit is ON, to activate health function

Press  again to deactivate health function.

Advance Function



Press  to switch between degree Celcius and degree Fahrenheit.

Compliance Information

Radio Frequency Interference



FCC Caution



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.



 www.dellahome.com

 support@dellahome.com

 800-863-4143

 6:00 a.m. – 4:00 p.m. PST Monday – Friday

© Della All rights reserved.

The design and specifications are subject to change without prior notice for product improvement. Any updates to the manual will be uploaded to the della website.
