



FLEX SERIES

REFLEX CARRY HANDLE
TRH

OWNER'S MANUAL



SEIZE THE NIGHT

TABLE OF CONTENTS

PRODUCT OVERVIEW

PAGE 1


HOW TO USE

PAGE 2

GET STARTED

PAGE 3

PRODUCT OVERVIEW



1	Picatinny Rail	3	Carry Handle
2	Internal Battery Storage	4	Storage Cap

HOW TO USE

The Flex Series Thermal Carry Handle (TRH) enables users to convert their thermal firearm sight to a handheld thermal viewer. This makes your Flex Series thermal optic more versatile and allows for use in a wide variety of scenarios. The waterproof cap may be removed for convenient battery storage inside the carry handle.

This accessory is designed for compatibility with Picatinny-mount devices, including the X-Vision Optics TR2, TR1, and TRW1.

GET STARTED

- 1. Open the quick-release lever of the Picatinny mount on your Flex Series device.**
- 2. Slide the device mount onto the Picatinny rail of the Carry Handle.**
- 3. Close the quick-release lever once the device is in place.**
- 4. Unscrew the storage cap at the base of the handle to access the battery storage compartment inside the handle.**



Contact Us

5140 Moundview Drive
Red Wing, MN 55066 USA

(833) 993-2383 (US)
(651) 385-2276 (Canada)
support@xvisionoptics.com

SEIZE THE NIGHT
XVISIONOPTICS.COM