


QUICK START GUIDE

- Charge binocular before first use, approx. 3 hours.
- Press and hold the power button to turn binocular on/off.
- Bring the screen into focus using the focus dial.
- Zoom in with the focus dial as necessary.
- This may require many turns depending on range.
- For night vision press the IR button.
- For taking photos and video, install a memory card and press the camera button.



MELPFUL MINTS

- Night vision does not work through glass. The glass will reflect the IR light signal.
- To see in the dark, make sure to press and release the IR button.
- There are multiple IR levels. (press repeatedly to adjust).
- The higher the IR setting, the further you will see in the dark.
- ALWAYS make sure to turn off your binocular when not in use.
- You can adjust auto shut off under the mode settings (reference manual).
- Always power off binoculars before removing the memory card.

