



Origin

Changing the Set Combination Code

1. Open the Origin and slide back the lid.
2. Make sure the code is on the **set** combination code. The switch will not move if the code is on a different number sequence.
3. On the back of the combination lock move the switch (marked B) across and up.
4. Change the code to the number combination you would like to use.
5. Push the switch back down to **set** the combination code.

