

POWERPULL INSTRUCTIONS

Thank you for investing in the ProMAXX® PowerPull™ series fuel injector removal tool for select Ford® and Mazda® engines!

The device was engineered to speed the removal and reduce damage to the injectors plastic housing. The device is precision machined from anodized aluminum to encase the injector and to handle more pulling power while reducing damage compared to other pullers.

To use, drop the device alongside the injector and slide it over the o-ring and under the plastic flange portion of the injector. Grasp the injector tool by hand and lift it free. For more difficult injectors, consider the optional ProHammer $^{\text{TM}}$ shown at right. Simply thread the ProHammer into the top of the injector removal tool and use quick action to remove it.

OPTIONAL PowerHammer™ Kit (Consists of Hammer, Slide, Chrome Acorn Nut, & Impact Washer.

Compatible with:

Ford 2010-2021 F-150 (CM5253) 2007-2011 Edge 3.5L 2009-2012 Flex 3.5L 2010-2012 Fusion 3.5L 2008-2012 Taurus 3.5L 2008-2009 Taurus X 3.5L <u>Lincoln</u> 2009-2012 MKS 3.7L 2010-2012 MKT 3.7L 2007-2010 MKX 3.5L

2007-2012 MKZ 3.5L

<u>Mazda</u> 2009-2013 3.7L 2007 CX-9 3.5L 2008-2014 CX-9 3.7L Mercury 2008-2009 Sable 3.5L

Check out our other injectors at promaxxtool.com

SAFETY PROCEDURE: ALWAYS USE APPROPRIATE SAFETY EQUIPMENT INCLUDING OSHA APPROVED SAFETY GLASSES/GOGGLE AND PROTECTIVE GLOVES WHILE USING THIS DEVICE AND PERFORMING THIS OPERATION.





NEED HELP? WE LOVE HELPING OUR CUSTOMERS! DIAL 724-941-0941 We are only successful when you are



For video instruction, check out the QR code. Simply hover your phone camera over the image and it will connect you to our fast, easy Youtube tutorial.

