User Guide

The AnyDesk Nest Pro

Mobile Standing Desk

Assembly Instructions

Check
Parts

Before beginning assembly, ensure that all parts listed are present and undamaged. If any parts are missing or damaged, do not proceed with assembly process and contact customer support.

Follow
Steps

Assemble the product by following the steps in the provided order. Skipping steps or assembling out of order may result in misalignment or instability.


Screw Installation A. Insert Screws Loosely First

Begin by loosely inserting screws, leaving them about 80% tight. This allows for adjustments and ensures proper alignment before fully tightening. Fully tightening screws too early may cause alignment issues.

B. Fully Tighten After Alignment


Once parts are aligned, fully tighten the screws to ensure the product's stability and safety.


Stable Surface Assemble the product on a flat, stable surface to prevent parts from rolling or shifting during assembly. A stable surface helps to avoid damage and ensures a safer assembly process.



Parts

List







Desktop

X1

X1

X1

X4 Cable Clip




Set Up the Cover

1.1 Press the toggle switch and position the Leg (A) upright.

TopJob


1.2 Slide the **Cover (D)** through the leg and cord 1.3 Make sure the cord is tucked under the **Cover (D)** so that the cover can be secured on the desktop



2 Attach the Leg to the Desktop

2.1 Place the **Desktop (B)** upside down on a flat surface. Position the **Leg (A)** on the underside of the Desktop, aligning the screw holes as shown in the diagram. Secure the Leg to the Desktop using 6 **M6*16mm Screws (F)**. Tighten the screws with **the Allen Wrench (I)**.

2.2 Secure the cable with the **Cable Clip (K)** by using a phillips-head screw driver (not included in the package) to tighten the screw into the pre-drilled hole.



Attach the Feet to the Leg

Position and align the holes in the **Feet (C)** with the threaded holes in the **Leg (A)**.


Secure the Feet to the Leg using 4 M6*40mm Screws (I). Tighten with the Allen Wrench (I).



B

Add Desktop Bumper (Optional)

Tear off the 3M adhesive on the back of the bumper (E) and stick it to the appropriate position on the top of the desktop















Install The Accessories (Optional)

Ensure that you have the **TopJob ANYDESK Accessory Kit**, specifically designed for ANYDESKs, before proceeding with this installation step.

Parts List:




Installation Instructions:

Align the **M - Rotating Cup Holder** and **N - Hook** with the designated sets of holes on the right side, on the back of the desktop. Locate the pre-drilled holes by identifying the small dimples on the desktop surface.

Position the **P - Pointed Screw** in the corresponding hole and securely tighten it using a Phillips-head screwdriver (not included in the toolbox).


You can purchase the ANYDESK Accessory Kit at www.topjob.co/collections/accessories.



Adjustment


Height Adjustment

Lift the Paddle for lifting the table top. Lift the Paddle and press the table top for downward operation.




Tilt Adjustment

Press the tilt button to tilt the table surface to 90 degrees. Attention: There is a risk that objects on the surface may fall when tilting. Before performing this action, ensure the surface is clear of any items that could fall and become damaged.




Maximum Static Capacity: 110 lbs

For static use, it is recommended not to exceed a maximum load of 110 lbs on the desk top to ensure stability and long-term durability.



Maximum Dynamic Capacity: 17.6 lbs

It is recommended not to exceed a maximum of 17.6 lbs on desk top to allow for easy



Materials

| Тор | Performance Vinyl on High-Density Board |
|---------|---|
| Leg | High-Carbon Steel |
| Casters | PP + PVC |

Returns and Warranty

Return Policy

Warranty

Like-new TopJob products can be returned within 30 days if they are in original condition with all packaging. Return shipping costs are the buyer's responsibility. A restocking fee may apply.

> To start a return, contact support@tobjoblab.com with your order

For more details, visit www.topjob.co.

TopJob products are covered by a 2-year limited warranty, which covers defects in materials and workmanship under normal use. It does not cover damage from misuse, accidents, or unauthorized modifications.

To make a warranty claim, contact support@tobjoblab.com with your order number and details of the issue.

For full warranty details, visit www.topjob.co.

Work, Wellness, and More.

At TopJob, we believe that work is deeply personal. Recognizing that every individual has unique tasks, schedules, body types, and seating preferences, we are committed to transforming the way you experience your workspace.

Our mission is to design thoughtful furniture solutions that seamlessly adapt to you, enabling you to "get the job done, beautifully." We prioritize functionality over clutter, crafting smart pieces that enhance both productivity and well-being in your home and office.


With TopJob, you can build a workspace that genuinely fits your busy lifestyle, allowing you to do your best work.

Contact

Website www.topjob.co Email support@topjoblab.com



Specifications



| Overall Dimensions | 27.56"L×15.75"W×28.25-43.15"H |
|--------------------------|-------------------------------|
| Lift Range | 28.25"-43.15" |
| Maximum Static Capacity | 110 lbs |
| Maximum Dynamic Capacity | 17.6 lbs |
| Assembled Weight | 30.42 lbs |

| Тор | Performance Vinyl on High-Density Board |
|---------|---|
| Leg | High-Carbon Steel |
| Casters | PP + PVC |