

OPTICFIRE® AG-38/50/67/75 USER MANUAL

Charging

All AG lamps come with the 18650 Li-ion battery pre-installed, it is advised to charge the battery fully before the first use.

1. Plug the included USB cable into the charge port located on the end cap switch.
2. Plug the other end of the cable into a universal USB port/adaptor.

Always recharge after use. It is also advisable to charge the battery if it is not used for 3 months.

Charge Indicator Light

Charging a fully depleted battery takes approximately 6 hours.

A red light around the charge port indicates that the battery is charging, when the LED changes to green the battery is fully charged.

Please note. Once the charge indicator light has changed to green the battery will stop charging so you cannot over charge the battery.

Switching ON/OFF

To switch ON: Press the button on the tail cap until a “click” is heard.

To switch OFF: Press the button on the tail cap a second time until a “click” is heard.

Mode Switching (for 3 mode LED)

To change the mode press the button on the tail cap half way, each half press will change the mode from high/med/low.

3 mode LED have a built in 2 second memory meaning that if the lamp is switched off for 2 seconds or more the next time it is turned on it will remember the last mode used.

Zoom Function

The AG lamp can be zoomed from a wide angle flood to a tight spot by twisting the torch head.

Turn anti-clockwise: Spot

Turn clockwise: Flood

Changing The LED Pill

Before you start make sure the torch head is in the flood position.

1. Grip the front anti-glare shroud section and unscrew in anti-clockwise direction.
2. Remove anti-glare shroud & glass lens.
3. Grip the silver LED pill with your fingers and turn in clockwise direction until it is removed.
4. Screw new LED pill in anti-clockwise direction.
5. Replace glass lens and anti-glare shroud.

Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicone based lubricant.