


The GigRig™ Distributor

The GigRig Distributor works as part of our Modular Power Supply to distribute power across your pedalboard. The Distributor has six non-isolated 9v outputs that can deliver HUGE amounts of current when needed. Use The GigRig Generator to power your Distributor and from there you can add Isolators, High Current Adapters, Virtual Batteries and Cable Adapters to correctly power your DC powered equipment.



Instructions for use:

Each Distributor is supplied with 6 x 1.5 metre length DC leads with right angled 2.1mm connectors to power your equipment. Simply follow the instructions listed in the diagram provided to correctly connect them.

Please note, we cannot guarantee the performance of the adapter from any other power supply.

DO NOT STRIP THE CABLE.

DO NOT COVER THE ADAPTER, IT MAY OVERHEAT AND SWITCH OFF!

It is normal for the adapter to run warm.

The GigRig Distributor is designed for indoor use. (Just don't get it wet!).

Fully compliant with **RoHSV** (lead free product.)

CE Approved.

www.thegigrig.com




Wire with white stripe in white key Black wire in black key

Warning! - Reversing the wires may damage your pedal



1. Measure and cut the cable to length
2. Slightly separate the ends and insert in Distributor
3. Using cutters, or similar, press down firmly till button is fully flush with surface.



- *The perfect pedal board in minutes, with no soldering
- *Uses right angle 2.1mm centre neg d.c. connectors
- *Link Distributors together for larger pedal boards
- *Easy to undo and reuse
- *Use with TheGigRig Generator and Virtual Batteries to power almost any d.c. powered pedal

Warranty:

The GigRig warrants the product to be free from defects in material and workmanship for a period of 2 years from the original date of purchase. If the product fails within the warranty period, The GigRig will repair or, at our discretion, replace the product and cover the cost of return shipping to the original purchaser. This warranty covers defects in manufacturing discovered while using this product as recommended by The GigRig. This warranty does not cover loss or theft, nor does the coverage extend to damage caused by misuse, abuse, unauthorized modification, improper storage, lightning, or natural disasters. Damage caused by any of the above circumstances may result in a non-warranty repair fee.

Legal:

In the case of malfunction, the purchaser's sole recourse shall be repair or replacement, as described in the preceding paragraphs. The GigRig will not be held liable to any party for damages that result from the failure of this product. Damages excluded include, but are not limited to, the following: lost profits, lost savings, damage to other equipment, and incidental or consequential damages arising from the use, or inability to use this product. In no event will The GigRig be liable for more than the amount of the purchase price, not to exceed the current retail price of the product. The GigRig disclaims any other warranties, express or implied. By using the product, the user accepts all terms herein.

Disposal:

Return the unit to The GigRig Ltd for disposal or use standard disposal for electrical equipment recommended in your country

