

THANK YOU for your purchase at Led Nordic

We hope you enjoy your purchase with us and the little glimpses of life.

This user manual is intended for solar/Rechargeable lights.

Specifications:

- Material UV-resistant White PE-Plastic
- Charging Solar cell or Usb charging
- Battery Rechargeable Lithium battery 3.7V. 1200 MaH
- Temperature -14°C - 35°C
- Charging time 8 hours in full sun or 6-8 hours by USB
- Battery life 6-8 hours
- Remote control Yes - sold separately
- Colour Warm white LED
- IP 44
- Effect 1W/5V
- Connect 220-240V

Warning.

- The remote control battery can cause choking. Use caution.
- Do not open or attempt to repair these products yourself.
- Keep the product away from chemicals or heat that can damage the lamp.
- Do not sit or stand on the lamp.
- The product cannot be left in large amounts of water, such as puddles or similar.
- Clean with a damp cloth.

Instruction manual

- Carefully remove the lamp from the packaging and remove the plastic card at the bottom of the remote control.
- Place the light in a location where it can reach a full 8 hours of sunshine to maximise battery capacity.
- We recommend keeping the light switched off for 24 hours to charge the battery well.

Switch on and adjust the brightness:

- To switch on the light, press the ON /OFF button on the bottom of the light.

See the instructions below for remote control.(buy separate article 90001)



- 1 Switch on
- 2 Switch off
- 3 Decreasing brightness
- 4 Increasing brightness

Troubleshooting and caution:

If your light is not working properly at night, it could be due to one of the following;

- Press the "on" button on the remote control.
- Make sure the lamp is sunny and not in the shade.
- The lamp needs to be charged for approximately 6-8 hours for optimal condition by USB or 8 hours outside for full sunlight.
- Keep the lamp off for 24 hours to charge the batteries well (press the OFF button on the remote control)

If the remote control no longer works when any button is pressed:

- Make sure to get a distance of less than 10 metres between the remote control and sunlight (open area)
- Replace the remote control battery.

Safe for outdoor use. Low winter light may make you decide to store your light indoors until light conditions improve. Clean and dry the solar ball, switch off the switch or remove the battery. Store the product in a dry place.

Should have any questions about the product, you are more than welcome to contact us.

With best regards

LED  NORDIC

Enjoy the little glimpses

Imported by:

Mrkk aps

Stokagervej 5

8240 Risskov

Denmark

Cvr 36891963

www.led-nordic.com

@Led_nordic