

Tips for installing Flex Fuel kits based on PCM Type

Non-vehicle specific guide to pin outs for various PCM types.

*This is not to be considered an all-inclusive Install Guide and will not cover the basics for power connections nor fueling connections, this guide should be used only by professionals where an in-depth install guide isn't available for your specific application. Consult your tuner if you are unsure which PCM/ECM you have.



E40 PCM/ECM Connector #3 Pin #4



E38 PCM/ECM Connector #1 Pin #40



E67 PCM/ECM Connector #1 Pin #5



E92 PCM/ECM Connector #1 Pin #38



411 PCM/ECM Connector #1 Pin #56



E59 PCM Connector #1 Pin #56