

Components Check List

Comfort Soul Soul

Hydraulic \mathscr{P}_{ro}



- CAUTION -



When a client is getting on the chair:


ALWAYS have the chair locked

-AND-


 Make sure the bed set in a parallel position to the base as shown.


CONTENTS







Soul SOUL















- CAUTION -




When a client is getting on the chair:

ALWAYS have the chair locked

- AND -

 Make sure the bed set in a parallel position to the base as shown.





- ①Both metal poles on each armrest must be inserted simultaneously.
- ②When removing the armrest from the chair body, you must press the button located under the armrest holes before pulling the armrest out.

Warning: Do no try to rip plastic protector from furniture. This action may damage the product. Protective plastic needs to be carefully removed with scissors.

VINYL AFTERCARE



- 1.Use soft cleaning implements. Only clean your vinyl seats with soft sponges, dish cloths, and soft-bristled brushes. This will ensure your vinyl seats last for many years.
 Using steel wool, sharp cleaning tools, or similarly abrasive cleaning implements could cause your vinyl seating to tear.
- 2. Wash your vinyl with soapy water. Mix a small amount of mild dish soap with warm water until the mixture is sudsy. Dip a soft-bristled brush or soft cloth in the water. Scrub the vinyl seats until clean.
- **3. Do not use abrasive cleaning compounds.** Undiluted bleach, for instance, is too caustic to use on vinyl. Over time, cleaning your vinyl seats with bleach will cause them to break down. [6] Likewise, avoid cleaning compounds containing: [7]
- concentrated detergents
- silicone oils
- waxes
- petroleum distillates
- dry cleaning fluids
- solvents
- acid-based cleaners