

Before you begin

Scan for easy 3D instructions



USA/ États-Unis 1006149128
 Canada 1001618102
 YOW 1006033377



ASSEMBLY REQUIRES AT LEAST 2 ADULTS, 3 ADULTS ARE RECOMMENDED. PLEASE FOLLOW THE STEP BY STEP GUIDE AND ENJOY YOUR 12FT INFERNO PUMPKIN SKELETON!

IF ANY PART IS MISSING OR BROKEN, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT SVI CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921, EMAIL CUSTOMERSERVICE@SVIUS.COM, OR CALL THE HOME DEPOT CUSTOMER SERVICE AT 1-877-527-0313.

EASY ASSEMBLY AND OPERATION INSTRUCTIONS

21SV22947_12FT Inferno Pumpkin Skeleton

READ AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE


IMPORTANT TIPS:

- If not functioning properly (eyes, mouth, chest don't light up), ensure that cables are connected to their corresponding cable as shown in the instruction sheet (See steps 5.1 and 7.2).
- If item does not activate when turned on, ensure that the adapter is plugged into a live outlet.

- If the item still does not work, contact SVI customer service from 8:30am to 5:30pm PST at 1-855-428-3921, email customerservice@svious.com, or call The Home Depot customer service at 1-877-527-0313.



PARTS LIST

- A. Base x 1
 - B. Base Extension x 4
 - C. Right Foot x 1
 - D. Left Foot x 1
 - E. Lower Support Pole x 2
 - F. Right Lower Leg x 1
 - G. Left Lower Leg x 1
 - H. Right Upper Support Pole x 1
 - I. Left Upper Support Pole x 1
 - J. Upper Right Leg x 1
 - K. Upper Left Leg x 1
 - L. Lower Torso x 1
 - M. Spinal Support x 1
 - N. Chest x 1
 - O. Right Upper Arm x 1
 - P. Left Upper Arm x 1
 - Q. Left Arm and Hand x 1
 - R. Right Arm and Hand x 1
 - S. Head x 1
 - T. Loop Screw x 1
 - U. Cable x 1
 - V. Stake x 4
 - W. Allen Wrench x 1
 - X. Adapter * x 1
- * Power Adapter Spec
 Input: 120VAC 50/60Hz
 Output: 5.9V 1.5A




If your application needs sturdier stakes, check out SKU 1006262796 at The Home Depot (sold separately).

NOTE: Throughout the instructions, Right and Left are relative to the character. Allen wrench included for assembly. A stepladder is recommended for assembly. The hooks on the (A) Base are towards the back of the item. Only 2 of the (B) Base Extensions are assembled at the back of the base for now.




NOTE: Slide the two upper legs onto the upper support poles and then fit them onto the lower legs as shown.




3.1


NOTE: A ladder and more than 2 people are advised when assembling the (L) Lower Torso to the (I) Upper Support Poles and the (J, K) Upper Legs.



1



2




3

If there is difficulty in assembling the (L) Lower Torso, try adjusting the upper legs until they are properly aligned.

3.2

NOTE: Lean the 12FT Inferno Pumpkin Skeleton against the box it came with for easier assembly. 3 adults are strongly recommended for this step.




Outer box

4.1



4.2


NOTE: Guide the (N) Chest carefully over the (M) Spinal Support. Guide the top of the (M) Spinal Support out of the hole available at the top of the (N) Chest.



NOTE: After connecting the wires, hide the excess inside the available cavity at the bottom of the (N) Chest. Ensure that the wire is not pinched between the (N) Chest and (L) Lower Torso.


5.1

NOTE: Screw the loop into the area inside of the (M) Spinal Support as shown. Place your free hand into the (N) Chest to guide the (T) Loop Screw into the housing.




5.2

Note: Do NOT overtighten this bolt. Overtightening may result in damage to the product. Adjust the arm position to your preference. If a bolt is missing, check inside the box as it may have fallen out of the arm. Repeat this step on the left side to attach the (P) Left Upper Arm.



6.1



6.2

NOTE: Make sure hands are oriented properly. The palms of the hands should be aimed towards the (A) Base.

6.2

CAUTION: Cable may have sharp ends, use caution when assembling. If cable cannot reach, the upper body of the 12FT Inferno Pumpkin Skeleton needs to be lifted while in its laying position. This should enable the cable to reach.

7.1

CAUTION: Make sure head is locked into place.

After connecting the wires, hide the excess inside of the available cavity at the top of the (N) Chest. Ensure that the wire is not pinched between the (N) Chest and (S) Head.



7.2




NOTE: When plugging the adapter into the 12FT Inferno Pumpkin Skeleton, ensure that the cap on the adapter cable is twisted clockwise until firmly in place as shown.

ADAPTER 8.1


CAUTION: The (U) Cable must be secured before erecting the 12FT Inferno Pumpkin Skeleton. It is strongly advised that 3 adults participate in the assembly, standing the 12FT Inferno Pumpkin Skeleton, setting the 12FT Inferno Pumpkin Skeleton down, and disassembly. The item must be laid down for disassembly.



If your application needs sturdier stakes, check out SKU 1006262796 at The Home Depot (sold separately).



NOTE: Power button on the back of the (L) Lower Torso. Position 12FT Inferno Pumpkin Skeleton on flat surfaces only. Your 12FT Inferno Pumpkin Skeleton is now fully assembled. Use the adapter and turn on to let the fun begin!



NOTE: The arms can be posed to your preference. Please pose the arms before erecting, otherwise a ladder will be needed.



© Seasonal Visions International Limited
 All Rights Reserved
 Tous droits réservés
 Reservados todos derechos
 Made in China
 Fabriqué en Chine



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.

CANICES-3(B)/NMB-3(B)

WARNING:

- Lay product down before a storm or strong winds.
- Don't climb or pull on product.
- Don't add to or modify product.
- Assemble and place the product on level surfaces only.
- Don't push or tilt product.

WARNING

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by manufacturer.
2. Please assemble item according to instructions. Connect all wires according to matching color.
3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

CARE AND STORAGE INSTRUCTIONS

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

OPERATION INSTRUCTIONS:

The 12FT Inferno Pumpkin Skeleton is powered by an adapter. Plug the power adapter into a standard power outlet. To turn on the 12FT Inferno Pumpkin Skeleton, press the button underneath the (L) Lower Torso once. Press the button again to switch to the Timer setting. Press the same button a third time to turn the item Off.

The item is activated by pressing the button on the (L) Lower Torso and has the following settings:

On	This setting will activate the eyes, mouth and chest of the item.
Timer	This setting will activate the eyes, mouth and chest of the item for 6 hours at a time. The time will then turn off and turn on once again after 18 hours.
Off	This setting will deactivate the eyes, mouth and chest of the item.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.
 CAN ICES-3(B)/NMB-3(B)

 WE SUGGEST AT LEAST TWO ADULTS FOR ASSEMBLY	 NO MOVING AFTER FULLY ASSEMBLED	 LEVEL AREA ONLY	 USE ADAPTOR	 DO NOT DISPLAY DURING STRONG WINDS
 DO NOT PUSH OR TILT	 DO NOT CLIMB OR PULL ON	 DO NOT ADD TO OR MODIFY (ADD COSTUME KITS FROM THE HOME DEPOT ONLY)	 CONTACT US IF EYES, MOUTH, CHEST DON'T WORK PRESS ON	 CONTACT US 1-877-527-0313